Panasonic Broadcast Mechanical Parts List

Model No.: AG-HPG10P/E/MC


Note:

- 1. *Be sure to make your orders of replacement parts according to this list.
- 2. Unless otherwise specified, all resistors are in OHMS, K=1,000 OHMS, all capacitors are in MICROFARADS (μF), P=μμF.
- 3. The P.C. Board unit marked with "■" shown below the main assembled parts.
- 4. The parts marked with ©on the exploded view show the electric parts.
- 6. The marking (RTL) indicates the retention time is limited for this item.

 After the discontinuation of this assembly in production, it will no longer be available.
- 7. "M" in Remark column indicates needed in the periodical maintenance.

CONTENTS

CASING PARTS ASSEMBLY	MPL-1
TOP CASE & LCD PARTS ASSEMBLY	MPL-3
PACKING PARTS ASSEMBLY	MPL-5




MPL-1

CASING PARTS ASSEMBLY


	•						1	_	
Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	s Remarks
1	VGF1078	JACK COVER	1						
2	VGH4966	JACK LABEL	1						
3	VYK2H60	BATTERY CASE 1U	1						
4	VGU0B45	BATTERY LOCK BUTTON	1						
5	VMB4036	BATTERY LOCK SPRING	1						
6		BATTERY BOTTOM PLATE	1						
7		BATTERY LOCK PLATE	1						
8		SDI CABLE (RED)	1						
9	VEE1D85	1394 CABLE	1						
10	VMT1880	EMC GASKET REAR TOP	2						
11	VMT1881	EMC GASKET REAR BOTTOM	1						
12	VGP6216	USB PANEL	1						
13	VMP8857	USB PLATE	1						
14	VMG1800	USB CAP	1						
15	VYK2G18	FRONT PANEL 1U	1						
	VYK2G19	FRONT LID U	1						
	VKM7167	MAIN FRAME	1						
18	VMT1857	GASKET B	3						
19	VMF0578	PROTECT TAPE	2						
20	VMP8959	MAIN SHIELD PLATE	1					_	
21	VMZ3531	HEATING SHEET (DECO)	1					_	
22	VMT1892	EMC GASKET	2					_	
23	VMP8958	P2 EARTH PLATE R	1	FOR AC LIDOTOR				-	1
. 24	VGNOW53	RATING LABEL	_	FOR AG-HPG10P				-	1
	VKM7168	BOTTOM CASE	1					_	
26	VKA0390	LEG NEW		EOD AC-UDC1OD	 			-	1
28	VQL2617	SEE MANUAL LABEL	1	FOR AG-HPG10P				_	
		CARD HOLDER A CARD HOLDER B	1		 			-	1
30	VMP8554	P2 CARD ANGLE A	1		[\vdash	
	VMP8555	P2 CARD ANGLE A P2 CARD ANGLE B	1						
32	VMZ3718	P2 ANGLE BARRIER	1						
34	VGQ8877	LCD FPC TAPE	1						
35	VMZ3717	FFC CUSHION	1		-				
30	VWIZ3/1/	FFC COSTION	-		-				
					-				
101	XQN16BJ25FJK	SCREW	3						
102	XQN2+BJ6FJK	SCREW	2						
103	XTB2+4GFJ	SCREW	6						
	XTB3+8GFJK	SCREW	3						
105	XYN2+J6FJK	SCREW	14						
	XSN3+6FJK	SCREW	2		-				
	XYN2+J6FJ	SCREW	24						
108	XQN2+B4FN	SCREW	4					H	
100	XQN2+B25FJ	SCREW	5					H	
110	XQN16+B2FJK	SCREW	2					Т	1
111	VHD1887	SCREW	1						
			† ·					Т	1
								Т	1
								Ħ	
E1	VEP03H15A	V PROC C. B. A.	1						1
E2	VEP03H16A	CODEC C. B. A.	1					П	
E3	VEP03H17A	P2 CARD C. B. A.	1						
E4	VEP03H18A	AV OUT C. B. A.	1						
E5	VEP01991A	POWER C. B. A.	1						
E6	VEP01992A	BATTERY C. B. A.	1						
E8	VEP03H20A	JACK C. B. A.	1						
E10	VEP03H22A	USB C. B. A.	1						
E11	VEP03H26A	1394 CN C. B. A.	1						
E14	VEP001S7A	R INTER CN1 C.B.A.	1					L	
E15	VEP001S8A	R INTER CN2 C.B.A.	2						
								П	
								Т	1
								Т	1
	I		1		l 			Н	

TOP CASE & LCD PARTS ASSEMBLY



TOP CASE & LCD PARTS ASSEMBLY

1 V 1-1 V 1-2 V	/YK2E76	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
1-1 V 1-2 V	/YK2E76	I CD II							
1-1 V 1-2 V	/YK2E76	LCD II							
1-1 V 1-2 V		LUD U	1						
1-2 V	/YK2G36	LCD 1U	1						
		HINGE U	1						
		LCD BACK LIGHT	1						
		LCD BARRIER	1						
		SHADING PLATE	1		-				
		MONITOR KNOB	1						
			1						
		RUBBER BUTTON							
		ORERATION BUTTON	1						
		MONITOR LOCK KNOB	1						
		HANDLE S/S BUTTON	1						
		NYLON NUT	1						
		TOP CASE	1						
9 V	/MB3659	MONITOR OPENER SPRING	1						
		POP UP SPRING	1						
	/MG1286	CUSHION RUBBER	2						
		HEADPHONE CAP	1						
		OPENER HOLDER ANGLE	1						
		LCD LOCK SHAFT	1						
		CLATCH SPACER	1						
	/WJ06H2033L0			6PIN 33MM	-				
		LCD HINGE COVER FRONT	1	OI IN JOHN	<u> </u>				
					-				
		FPC LOCK SHEET	1						-
	/WJ30H2070L0		1						4
		FFC BARRIER	1						
		LCD CAUTION LABEL	1						<u> </u>
	/GL1245	LED LENS	1						
		FPC PROTECTION SHEET A	1						
24 V	/MT1896	FPC HOLD CUSHION	1						
101 X	(YN2+J6FJ	SCREW	8						
		SCREW	2						
		SCREW	2						
		SCREW	4						
		SCREW	2						
107 1	VIINZ+00F0	SUNLII							
									
									<u> </u>
L									
		TOP OP C. B. A.	1						
	/EP03H21A	LCD C. B. A.	1						
		LCD SENSOR C. B. A.	1						
E13 V	/EP04928A	HEADPHONE C. B. A.	1						
									1
			H						1
 									+
 			H		<u> </u>				
					—				1
			Н		<u> </u>				-
ļ									
			Ш						
									1
									†
 			H		—				
 			H		-				+
			H		-				
ļļ.					-				1
			Ш						
ļ									
					1			1	1
			_					_	



Components identified with the mark Ahave the special characteristics for safety. When replacing any of these components, use only the same type.

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
1	VPG1P66	PACKING CASE	1	FOR AG-HPG10P	l				
1	VPG1P68	PACKING CASE		FOR AG-HPG10E					
1	VPG1P69	PACKING CASE	1	FOR AG-HPG10MC	-				
	VPG1P70	PACKING CASE		FOR AG-HPG10MC					
		CUSHION F	1	TON AU TII UTOIIIO					
	VPN6619	CUSHION R	1						
5	VPF1136	PROTECT BAG	1						
6	VQT1H84	OPERATING INSTRUCTIONS		FOR AG-HPG10P					
. 6	VQT1H85	OPERATING INSTRUCTIONS	1	FOR AG-HPG10E					
4 6	VQT1H86	OPERATING INSTRUCTIONS	1	FOR AG-HPG10MC					
2 9	DE-A20BB	AC ADAPTOR U		FOR AG-HPG10P					
2 9	DE-A20CC	AC ADAPTOR U		FOR AG-HPG10E/MC					
10	K2KYYYY00028	CONVERSION CABLE	1	,					
	K2GJ2DZ00024		1						
12	K2RYYYYY0001	ADAPTOR PLUG	1						
		ACCESSORY BOX	1						
. 14	VYC0944	AC CORD U	1	FOR AG-HPG10P					
14	VYC0945	AC CORD U		FOR AG-HPG10E					
14	VYC0947	AC CORD U	1	FOR AG-HPG10MC					
. 15	VYC0946	AC CORD U	1	FOR AG-HPG10E					
			L	<u></u>				L	
			L						
			Ĺ					Ĺ	
-									
-									
-									
					l 				
			-		l 			\vdash	
J									i